

RM Cockspur Handle

Standard security | Locking | Simple to fit

Fitting Instructions

With the window in the closed position, measure the window over-rebate height indicated as “**Dimension A**” in the diagram below the table.

Check “**Dimension A**” against the table (right) to identify the spur wedge / frame wedge combination required.

Screw the appropriate spur wedge onto the handle spur using the screws provided.

Replacing an Existing Handle

With the handle in the fully open position, and using suitable fixings, screw the new handle onto the window sash through the existing screw holes. The existing frame wedge can be used.

Fitting onto a New Window

With the handle in the fully open position, and using suitable fixings, screw the handle onto the window sash **leaving a gap of 5mm between the side of the handle and the frame.**

Position the frame wedge directly under the handle spur and mark the position of the frame wedge studs. Drill the marked holes with a 5mm drill and push fit the frame wedge.

If the window operation is too slack or too tight, alter the wedges accordingly.

Check the operation of the window and if correct the frame wedge can be glued into position.

Cleaning

Window handles should be cleaned with a soft, dry cloth. If further cleaning is required we recommend a mild solution of warm, soapy water on a soft cloth. Dry thoroughly afterwards.

“Dimension A”	Spur Wedge	Frame Wedge
4mm	9mm	5mm
5mm	-	-
6mm	9mm	3mm
7mm	9mm	2mm
8mm	13mm	5mm
9mm	9mm	-
10mm	13mm	3mm
11mm	13mm	2mm
12mm	17mm	5mm
13mm	13mm	-
14mm	17mm	3mm
15mm	17mm	2mm
16mm	-	5mm
17mm	17mm	-
18mm	-	3mm
19mm	-	2mm
20mm	17mm	3mm
21mm	-	-

